


## Adapteur droit Mâle BSP X Mâle GAZ Conique







S MBSP X MR

				_						
PT123	BSP (E)	R (F)	L1	L2	LL	d1	d2	н		
1AA12050	G1/8-28f	R1/8-28f	8	10	24	3,5	3,5	12		
1AA14070	G1/4-19f	R1/8-28f	11	10	28	4,5	4,5	14		
1AA14080	G1/4-19f	R1/4-19f	11	14	32	4,7	7	14		
1AD22093	G1/4-19f	G3/8-19f (1)	13	12	33	6	6	22		
1AA17110	G3/8-19f	R1/4-19f	12	14	33	7	7	17		
1AA17120	G3/8-19f	R3/8-19f	12	15	34	7,9	7,9	17		
1AD27096	G3/8-19f	G1/2-14f (1)	12	14.5	80	7.9	14	27		
1AA21150	G1/2-14f	R1/4-19f	14	14	36	11,1	7	21		
1AA21160	G1/2-14f	R3/8-19f	14	15	37	10	10	21		
1AD22095	G1/2-14f	G3/8-19f (1)	18	12	40	8	8	22		
1AD27094	G1/2-14f	G3/8-19f (1)	14	11.2	60	11.1	9	22		
1AA22170	G1/2-14f	R1/2-14f	14	19	41	11,1	11,1	22		
1AD27098	G1/2-14f	G1/2-14f (1)	15	15	42,5	12	12	27		
1AA24210	G5/8-14f	R3/8-19f	16	15	39	14,3	10	24		
1AA24220	G5/8-14f	R1/2-14f	16	19	43	13	13	24		
1AA27250	G3/4-14f	R3/8-19f	16	15	40	16,7	10	27		
1AA27260	G3/4-14f	R1/2-14f	16	19	44	16,7	13	27		
1AA27270	G3/4-14f	R5/8-14f	16	19	44	16,7	14	27		
1AA27280	G3/4-14f	R3/4-14f	16	20	45	16,7	16,7	27		
1AA34300	G1"-11f	R3/4-14f	19	20	49	22,2	18	34		
1AA34310	G1"-11f	R1"-11f	19	24	53	22,2	22,2	36		
1AA42330	G1"1/4-11f	R1"-11f	20	24	54	28,6	24	42		
1AA45340	G1"1/4-11f	R1"1/4-11f	20	25	57	28,6	28,6	46		
1AA50360	G1"1/2-11f	R1"1/4-11f	22	25	59	31	31	50		
1AA50370	G1"1/2-11f	R1"1/2-11f	22	25	59	33,3	33,3	50		
1AA60390	G2"-11f	R1"1/2-11f	25	25	65	46	38	60		
1AA63400	G2"-11f	R2"-11f	25	30	70	46	46	65		
1AA77410	G2"1/2-11f	R2"1/2-11f	30	36	90	58	58	80		

<sup>(1)</sup> Prolongation en Gaz cylindrique au lieu de Gaz conique R.