






INSTALLATION





REVERSING POSITION OF THE WATER SUPPLY
INVERSER LA POSITION DU ROBINET FLOTTEUR



MAINTENANCE

