


NOTICE DE MONTAGE ET GUIDE DE MAINTENANCE



INDI36948




INDI36949

INDI36950



	Min.-Max. 1 - 5 bar		Max.60°C
	Max. 5 bar		3 bar
Pressure (bar)		Flow Rate (L/min)	
1		3.8	
2		5	
3		5	
4		5	
5		5	

Montage



Maintenance

